

## IRD JTAG Interface Adapter pin out diagram.


DTC-100 **5V**  
16-Pin Header



DP-301.013 **3.3V**  
(No Hole)16 Pin Header



DRD 420 RE **5V**  
14 Pin Header



DP-301.010

**3.3V** Pads



DP-301.013

**3.3V** Pads



DP-501

**3.3V** Pads



x700, x800, x900

**5V** Pads



6000

**3.3V** Pads



- No Connection
- TMS
- TCK
- TD1
- TD0
- TRST
- Ground -towards the front.
- Hold low for 3 seconds during power up for programming.